

BENINCA®



SELETTORE A CHIAVE
KEY SELECTOR
SCHLÜSSEL-SELEKTOR
SÉLECTEUR À CLEF
SELECTOR A LLAVE

benz-bau.ch GmbH


Doors + Openers

Kriessernstr. 16 - 9462 Montlingen - Fon: 071 761 40 60 - Fax: 071 761 07 78

CH



Collegamento APRE / CHIUDE OPEN / CLOSE connection




Al contatto APRE.
To OPEN contact.

Al contatto CHIUDE.
To CLOSE contact.

Al contatto comune "+V" della centrale.
To common contact "+V" of control board.

Schema elettrico Electrical layout



C
Comune
Common

NO
Normalmente aperto
Normally open

NC
Normalmente chiuso
Normally closed


NC
Normalmente chiuso
Normally closed

NO
Normalmente aperto
Normally open

C
Comune
Common

24V - 1A max.

Collegamento APRE - CHIUDE / STOP OPEN - CLOSE / STOP connection



Al contatto STOP.
To STOP contact.

Al contatto PASSO-PASSO.
To STEP by STEP contact.

Al contatto comune "+V" della centrale.
To common contact "+V" of control board.